



ON / OFF




ON : click
OFF : ⌘ 2 sec.


Volume & LED




↓ Sink alarm settings



↻ Weak lift buzzer



↑ Vario settings



Here is your memo card !

Cut it out and place it into your backpack name tag window.



Form for a memo card with fields for Name, Tel, and Mail. It includes two diagrams: 'Weak lift buzzer' and 'Volume & LED'. The 'Weak lift buzzer' diagram shows a cycle between OFF and ON with a 'click click' label. The 'Volume & LED' diagram shows a cycle between a speaker icon and a 'click' label. The bottom of the card has the logo 'leBipBip+ Memo Card'.